



Instructions for use

for SPINNER Click-type  
Torque Wrenches

M 3 6 1 4 6 c

Please see inside

The following procedure is required to obtain the pre-set torque value of the wrench. During the final tightening of the connector, **apply pressure only at the very end (or corner) of the handle until it clicks.**

Holding the wrench handle in a normal manner (using the whole handle) as the wrench clicks will **NOT** produce the intended torque value. A higher grip on the handle (closer to the wrench) produces more torque. This is typical of all click-type wrenches.

SPINNER GmbH  
Erzgiessereistr. 33 • 80335 München •  
Germany  
Phone +49 89 12601-0  
Fax +49 89 12601-1292  
[www.spinner-group.com](http://www.spinner-group.com)

