

## **SPINNER I Product Manual**

Original instructions

# Dummy Load 10 kW

RF Interface 3 1/8" EIA

BN 546423C0200 BN 546423C0201



products.spinner-group.com



#### Content

1	Safety	3
1.1	About this product documentation	3
1.2	Intended use	3
1.3	Improper use	3
1.4	Qualifications of personnel	3
1.5	Safety signs and symbols	4
1.6	Signal words for hazard seriousness	4
1.7	Grouped safety messages for SPINNER broadcast products	5
2	Product identification	7
3	Function	7
3.1	General	7
3.2	Coolant	7
3.3	Heat exchanger	8
3.4	Coolant circuit of the liquid cooling system	8
3.5	Interlock loop	9
3.6	Operating and display elements	10
4	Storage	11
5	Transportation	11
6	Installation	12
6.1	Mechanical installation	12
6.2	Coolant level check and drain hose installation	14
6.3	Electrical installation	14
7	Commissioning and normal operation	16
8	Cleaning	16
9	Maintenance	17
9.1	Deaerating the cooling circuit	17
9.2	Checking glycol concentration	19
9.3	Correcting the coolant level	20
10	Warranty	21
11	Repairs	21
12	Demounting	22
13	Disposal	23
14	Spare Parts	24
15	Contacts	24



#### 1 Safety

### 1.1 About this product documentation

The Spinner group makes every effort to keep the safety standard of our products up to date to be able to offer our customers the highest possible degree of safety. Our products are designed and tested in accordance with the relevant safety standards. There is, however, still a danger of personal injury or damage to equipment if this chapter and the safety instructions in this documentation are not complied with. This documentation aims at persons commissioned with the transport, installation, commissioning, operation, cleaning, maintenance, repairs, demounting and disposal of SPINNER dummy loads. Read this documentation completely and particularly the chapter "Safety", before working with the product. Keep this product documentation available at the site and pass it on to the subsequent users. For all questions regarding the safety you can contact SPINNER at any time.

#### 1.2 Intended use

The intended use of the product is to terminate RF high power coaxial transmission lines. The dummy load BN 546423C0200 or BN 546423C0201 is designed to absorb RF power of max. 10 kW in broadcast or industrial indoor applications in operating rooms with restricted access. Access for authorized persons shall be regulated by the operator.

Details and other limits are given in the attached data sheet 546423C0200-BE.

The intended use of the product is assumed, if it is used in accordance with the requirements of the applicable product documentation and within its performance limits (see appendices data sheet, circuit diagram, material data sheet of the SPINNER coolant and the following safety instructions). Applicable local or national safety regulations and rules for the prevention of accidents must be observed in all work performed in conjunction with the product.

#### 1.3 Improper use

The improper use of the product involves the use of the product:

- in operating rooms with unrestricted access
- in outdoor applications
- in explosion-prone atmosphere
- for transporting people or loads
- without correctly connected interlock system
- with covered inlet or exhaust air openings
- with modifications not authorized by SPINNER
- in damaged condition
- for private purposes
- in conditions and environments beyond the limits given in this product documentation

Any other use than described in the chapter intended use and in this product documentation is improper use and therefore inadmissible.

#### 1.4 Qualifications of personnel

Installation, commissioning, operation, maintenance, repairs and demounting of the product require electrical and mechanical specialized knowledge. In order to ensure the safe use, these activities may therefore only be carried out by qualified technical personnel or an instructed person under the direction and supervision of qualified personnel. Qualified personnel are those who, due to professional training, knowledge and experience as well as their understanding of the relevant regulations, are able to assess the work assigned, to recognize possible hazards and to institute appropriate safety measures.

Qualified personnel must have appropriate safety equipment and must be trained in first aid.

The use of the product requires special training and a high level of concentration. It must be ensured that persons who use the product are physically, mentally and emotionally able to comply with the requirements, otherwise injuries or material damage may occur. The employer or operator must choose suitable personnel for use of the product.



#### 1.5 Safety signs and symbols

Safety signs are used on warning labels, stickers, in the product documentation and on the packaging of the product.

<u>^</u>				1	
Warning! General hazard	Warning! Danger of electric shock	Warning! Hot surface	PE terminal	Earth	Warning! High weight
Warning!  Non-ionised electromagnetic radiation	No access for persons with pacemakers	Use safety shoes	Use safety helmet	Use safety gloves	Observe product documentation

## 1.6 Signal words for hazard seriousness

Signal words are used on warning labels, stickers, in the product documentation, on specific danger spots and on the packaging of the product. They indicate the hazard seriousness in safety messages.

**DANGER** Indicates a hazardous situation conveying great risk which, if not avoided, will result in death

or serious injury.

WARNING Indicates a hazardous situation conveying moderate risk which, if not avoided, could result in

death or serious injury.

**CAUTION** Indicates a hazardous situation conveying minor risk which, if not avoided, may result in minor

or moderate injury.

**NOTICE** Indicates the possibility of faulty operation that can damage the product.

It is essential to make sure that the signal words described here are always used only in connection with the related product documentation and the related product. The use of signal words in connection with unrelated products or documentation can result in misinterpretation and thus contribute to personal injury or material damage.



#### 1.7 Grouped safety messages for SPINNER broadcast products

#### Entire or multiple phases of product lifecycle

- Unless otherwise specified, these products are not protected against penetration of liquids, gases, steam, etc. Failure to comply could result in electric shock or product damage, which could also lead to serious injury.
- Blocking of constructive openings on the product (ventilation slots, fine leaks etc.) must be prevented, because these are necessary for product operation. Failure to comply could lead to overheating and could result in burns, fire and electric shock.
- Any object that is not designed to be placed in the openings of the housing must not be used for this
  purpose. Doing so can cause short circuits inside the product and could result in electric shock, fire or
  injury.
- Depending on the function, certain products such as RF radio equipment can produce an elevated level of electromagnetic radiation. Considering that unborn babies require increased protection, pregnant women must be protected by appropriate measures. Persons with pacemakers may also be exposed to risks from electromagnetic radiation. The employer/operator must evaluate workplaces where there is a special risk of exposure to radiation and, if necessary, take measures to avert the potential danger.
- As with all industrially manufactured goods, the use of substances that induce an allergic reaction (allergens) such as nickel cannot be generally excluded. If you develop an allergic reaction (such as a skin rash, frequent sneezing, red eyes or respiratory difficulties) when using a SPINNER product, consult a physician immediately to determine the cause and to prevent health problems or stress.
- Should a fire occur, the product may release hazardous substances (gases, fluids, etc.) that can cause health problems. Therefore, suitable measures must be taken, e.g. protective masks and protective clothing must be worn.

#### **Transport**

- The product may be very heavy. In some cases, the user may require suitable lifting gear and means of transportation to avoid back or other physical injuries.
- Transport the product only in the original packaging. Do not unpack until immediately prior to installation. Failure to comply could result in death or serious injury.

#### Installation

- Do not place the product on heat-generating devices such as radiators or fan heaters. The ambient temperature must not exceed the maximum temperature specified in the product documentation or in the data sheet. Product overheating could result in burns, fire and electric shock.
- Do not place the product on surfaces, vehicles, cabinets or tables that for reasons of weight or stability are unsuitable for this purpose. Always follow the installation instructions of the manufacturer when installing the product and fastening it to objects or structures (e.g. walls and shelves). An installation that is not carried out as described in the product documentation could result in death or serious injury.
- Mains driven products must be operated only from a TN power distribution system. The operator is
  responsible for using an appropriate and sufficiently dimensioned AC power line. The AC power line must
  be externally fused according to the product documentation. Failure to comply could result in fire or
  electric shock.
- Operation of products with protection class I according to EN 61140 is permitted only with a mains cable
  with protective earth connection. The protective conductor continuity must be inspected by an electrically
  skilled person. Failure to comply could result in electric shock.



- All externally connected circuits for controlling, alerting and signalling have to be fed from ES1 type sources acc. to IEC 62368-1 only. The current in these circuits has to be externally limited by means of fuses to values indicated in the product documentation. Failure to comply could result in fire and electric shock.
- Dangerous voltage must not reach the product over the outer conductor/waveguide. Failure to comply could result in electric shock.
- If the product is equipped with a ground terminal connection (equipotential connection), the ground terminal must be connected sufficiently dimensioned to earth. Failure to comply could result in electric shock.

#### **Commissioning / Operation**

- Products in operation may be hot. Touching them could result in burns.
- Before applying RF-power to the product, ensure proper connection and matching (load, line, etc.) of all RF-connectors. Ensure sufficient mechanical rigidity of the RF-connections. Failure to comply could result in serious injuries by non-ionised electromagnetic radiation.
- Operation of the product with a damaged cable is not permitted. All cables must be checked on a regular basis to ensure that they are in proper operating condition. By taking appropriate safety measures and carefully laying the power cable, ensure that the cable cannot be damaged and that no one can be hurt or suffer an electric shock by e.g., tripping over the cable.
- Front panels, lids and covers must not be removed during operation. Otherwise, live components can be accessible. This could result in electric shock, fire and serious injury.
- If the product is subjected to pressure, the locally and nationally applicable guidelines for pressure vessels must be applied. Failure to comply could result in death or serious injury.

#### Cleaning

 Prior to cleaning, turn off all feeding transmitters and disconnect them from the power supply. Use a soft, lint-free, dry cloth for cleaning. Do not use chemical cleaners. Perform cleaning only after cooling-down.
 Failure to comply could result in electric shock and burns.

#### Repair

- Troubleshooting and repairs should only be carried out by qualified technical personnel or an instructed
  person under the direction and supervision of qualified personnel (see chapter 1.4 " Qualifications of
  personnel"). Observe the section safety messages and in particular chapter 1 "Safety" of this product
  manual. Failure to comply could result in death or serious injury.
- Do not modify the product and use only spare parts tested and approved by SPINNER. Failure to comply
  could result in death or serious injury.

#### **Disposal**

- The operator is responsible for disposing of the product according to national waste disposal regulations.
   Improper disassembly or disposal may be hazardous.
- If hazardous substances or operation materials are used for operation of the product, which must be
  periodically disposed of (e.g. coolant), these materials must be treated in accordance with the safety
  instructions of the hazardous substance or operating material manufacturer and the national waste
  disposal regulations. Also observe the relevant safety instructions in this product documentation. Failure
  to comply could result in serious injury and environmental damage.



#### 2 Product identification

The SPINNER dummy load BN 546423C0200 or BN 546423C0201 has a type plate containing the following information for product identification:



### Spinner GmbH Erzgiessereistr. 33 D-80335 München





Abschlusswiderstand / Load 10 kW 50 Ω

.. BN 546423C0200 / Ser.No.: ...... / Built: .... Netzanschluss / Mains connection: L, N, PE

Netzspannung / Mains voltage: 230 V AC ±10%, 50/60 Hz Wirkleistungsaufnahme / Real Power consumption: 0,8 kW

Nennstrom / Nominal current @ 230 V: 3,5 A Gewicht ca. / Weight approx.: 85 kg



## Spinner GmbH

Erzgiessereistr. 33 D-80335 München





Abschlusswiderstand / Load 10 kW 50  $\Omega$ 

.. BN 546423C0201 / Ser.No.: ..... / Built: .... Netzanschluss / Mains connection: L, N, PE

Netzspannung / Mains voltage: 115 V AC  $\pm 10\%$ , 50/60 Hz Wirkleistungsaufnahme / Real Power consumption: 0,8 kW

Nennstrom / Nominal current @ 115 V: 5.5 A

Gewicht ca. / Weight approx.: 85 kg

#### 3 Function

#### 3.1 General

The resistor element of the dummy load, consisting of a cylindrical ceramic substrate coated with special resistive material, absorbs the RF power and converts it into heat. An unpressurized liquid cooling system with coolant pump and closed cooling circuit is used for transferring the heat from the resistor element, via a heat exchanger with forced air cooling, to the surrounding area.

#### 3.2 Coolant

The coolant ANTIFROGEN N is a well-balanced yellow coloured mixture of distilled water, ethylene glycol and a rust preventative. The composition ensures excellent protection against corrosion and freezing. The coolant is available in 30 litres containers (SPINNER BN A74423).



Observe the attached material data sheet of the coolant when filling up, emptying or deaerating the cooling system or disposing of the coolant. For an updated copy of the material data sheet refer to the link or QR code below:

https://products.spinner-group.com/AntifrogenN






#### 3.3 Heat exchanger

A radiator fan is used for re-cooling of the heat sink.

**NOTICE** Ensure unobstructed air circulation to avoid overheating.

#### 3.4 Coolant circuit of the liquid cooling system

A pressureless closed cooling circuit with radiator fan is used for heat release. The coolant is pumped through the resistor element W and the heat exchanger K by means of the coolant pump P. The expanse vessel AB is added due to the thermal expansion of the coolant. The temperature of the resistor element is monitored by means of the temperature controller B1.



AB: Expanse vessel

B1: Temperature controller

K: Heat exchanger

M1: Radiator fan (heat exchanger) and coolant pump motor

P: Coolant Pump W: Resistor element



#### 3.5 Interlock loop

The internal interlock loop for protection of the dummy load consists of the interlock switch in mains monitoring relay, the interlock switch in the emergency stop switch, the interlock switch in the temperature controller and the motor protection switch integrated in the frequency converter. In principle the interlock loop works like four in series connected switches which are all closed during normal operation of the dummy load. Any open switch shuts down all transmitters connected to the interlock loop.


- The mains monitoring relay K1 opens in case of mains failure.
- The emergency stop interlock switch opens if the emergency stop S2 is triggered.
- The temperature controller B1 opens at resistor temperatures above 220 °C.
- The protection function of the frequency inverter FU1 for the radiator fan and coolant pump motor M1 opens at motor overload.



#### **WARNING**

Electric shock hazard Electric shock can cause severe burns and fatal injuries. Do not use the interlock loop for personal protection

#### Schematic diagram of the switching status during normal operation:




The internal interlock loop complies with the requirements for Electrical energy Source class 1 (ES1 type according to IEC 62368-1, safe separation, proof voltage resistance 4 kV ACpk to primary circuit). The maximum permissible voltage for the interlock loop and to the grounded housing is 42.4 V ACpk respectively 60 V DC. The power supply must be fully compliant with the ES1 type requirements. The circuit has to be limited externally to 1 A.



#### 3.6 Operating and display elements

#### Front view



- Coolant filling port cap with drain hose
   Coolant level indicator
   Emergency stop (S2)
   Red indicator light (H2)
   Green indicator light (H1)

#### Green indicator light "READY":

The green light indicates readiness for operation:

- Mains voltage is connected
- No fault occurred

#### Red indicator light "WARNING":


The red light indicates that the interlock loop of the load is interrupted. All transmitters connected properly to the interlock loop are turned off.

The red indicator lamp lights, if the mains voltage is connected and at least one of the following three conditions is true:

- Emergency stop triggered
- Resistor element temperature too high
- Motor protection FU 1 triggered

#### Rear view

- 6 Connection for Interlock loop (J2)
- 7 Mains connection (J1)
- 8 Pushbutton for pump (S1)
- 9 PE terminal





#### 4 Storage

Keep dry and avoid exposure to sudden temperature changes to prevent condensation.

Environmental conditions for storage are specified in the attached data sheet 546423C0200-BE. Do not unpack until immediately prior to installation.

**NOTICE** 

Do not remove any connector protection cap until immediately prior to installation to avoid formation of dust and scratches on sensitive RF contact surfaces.

Environmental conditions for storage see attached data sheet 546423C0200-BE.

#### 5 Transportation



#### **CAUTION**

Crushing Hazard

The dummy load is heavy. Crushing or falling may cause injuries.

Use suitable lifting gear approved to carry at least 85 kg.

Do not stand below the dummy load.

To ensure stability, keep the product in the supplied transport packaging until immediately prior to installation.


Do not lift the dummy load at the RF connector.

Do not stress the expanse vessel and the emergency stop.

Safety shoes and hardhat are required.



**NOTICE** Environmental conditions for transportation see attached data sheet TD-00060.





#### 6 Installation



Before you start, ensure to read and understand the section safety messages and in particular chapter 1 "Safety" of this product manual. Only electrically skilled persons should install SPINNER dummy loads in accordance with the national safety and accident prevention regulations.

Failure to observe could result in death or serious injury.

#### 6.1 Mechanical installation



#### WARNING

Crushing Hazard



Falling objects may cause death and serious injury.

The dummy load is heavy. Use suitable lifting gear only. The lifting gear must be approved to carry at least 85 kg.

Do not lift the dummy load at the RF connector.

Do not stress the expanse vessel and the emergency stop.

Use suitable fasteners if mounted in an elevated position.



Safety shoes are required. If it is necessary to stand below the dummy load during installation, safety shoes and hardhat are required.


#### WARNING



Electric shock hazard Electric shock can cause severe burns and fatal injuries.

Do not install and operate the dummy load in environmental conditions beyond the specifications given in the attached data sheet 546423C0200-BE. The dummy load is designed for indoor application on operating sites with limited access only.

#### Floor installation:




The dummy load must be installed on a flat and solid ground with bearing capacity higher than 85 kg to ensure stability. The front panel and main switch need to be easily accessible. Do not install the dummy load on escape routes, corridors or close to temperature sensitive equipment. Required floor space for best possible cooling capacity is specified in the installation drawing above. Slight unevenness of the floor can be compensated by means of the levelling feet. The load can be additionally fixed with the lower M6 mounting threads. The M6 threads near to the RF connector can be used for mounting a traverse to support the RF cable.

**NOTICE** Ensure unobstructed air circulation to avoid overheating.



#### Ceiling installation (exemplary illustration):



The dummy load can be installed below a solid ceiling with bearing capacity higher than 500 kg to ensure stability. The rear connector panel, emergency stop button and filling port need to be easily accessible. Do not install the dummy load close to temperature sensitive equipment. Ensure sufficient pass line heights and the required cooling air flow space, refer to floor installation.

#### **NOTICE** Ensure unobstructed air circulation to avoid overheating.

Mount the supplied 4 fasteners with the supplied M6 screws at appropriate positions. The recommended tightening torque for the M6 screws is 13.3 Nm.

For ceiling installation, the following required mounting parts are not part of delivery:

- 4 threaded rods M10 or 3/8", Tensile strength min. 400 N/mm², Yield point min. 240 N/mm²
- 8 nuts
- 8 large diameter washers

Recommended tightening torque for M10 or 3/8" nut: 30 Nm



#### 6.2 Coolant level check and drain hose installation

SPINNER supplies the dummy load with correct coolant level and deaerated cooling circuit. The dummy load is equipped with a level indicator. The marking indicates the minimum and the maximum permissible level of the coolant.

#### **NOTICE**


The coolant level may exceed the marked maximum at temperatures above 25 °C.

Check the coolant level prior to commissioning.

Prevent dry running of the coolant pump.

Follow the instructions given in chapter 9.3 if correction of the coolant

level is required.



- 1 Drain hose
- 2 Cap for coolant filling
- 3 Coolant level indicator
- 4 Maximum coolant level
- 5 Minimum coolant level
- 6 Collecting vessel

Connect the supplied drain hose (1) to the cap (2). Place a suitable collecting container (6) with a capacity of at least 3 litres next to the dummy load and insert the drain hose (1) into the collecting container (6). In the event of a malfunction with a sudden rise in pressure in the cooling circuit, escaping coolant is drained via the drain hose into the collecting container.

The expansion tank has a membrane for continuous adaptation to the ambient pressure

#### 6.3 Electrical installation



#### WARNING

Electric shock hazard

Electric shock can cause severe burns and fatal injuries.

Before you start ensure to disconnect your entire system from the power supply. Utilize appropriate devices and methods to prevent accidental energizing.



#### WARNING

High leakage current

Connect at least 10 mm<sup>2</sup> PE conductor permanently to separate PE terminal before connecting mains connector.



#### WARNING

Radio Frequency Hazard


Radio Frequency Power can cause burns, eye injuries and electrical shock.

Before connecting the RF cable, ensure to disconnect your entire system from the power supply. Utilize appropriate devices and methods to prevent accidental energizing.



NOTICE

To avoid overheating caused by RF overload ensure to connect all relevant transmitters to the interlock system of the dummy load prior to commissioning.



- Connect at least 10 mm<sup>2</sup> PE conductor with cable lug permanently to marked separate PE terminal (M6 screw).
- Mount the supplied interlock loop connector on a suitable cable and attach the connector to the dummy load according to the attached circuit diagram 48745-0E. Check proper function of the interlock system prior to commissioning. Do not use the interlock loop for personal protection.

The maximum permissible voltage for the interlock loop and to the grounded housing is 42.4 V ACpk respectively 60 V DC. The power supply must be fully compliant with the ES1 type requirements according to IEC 62368-1. The circuit has to be limited externally to 1 A.

 Mount the supplied IEC 60320-1 mains connector on a sufficiently dimensioned power cord (e.g. H05VV5-F 3 x 1,5 mm²) and attach the connector to the dummy load according to the attached circuit diagram. Use an easily accessible socket located close to the dummy load for mains connection. Connect the dummy load only to TN networks (L, N, PE):

BN 546423C0200 230 V AC, 50 Hz/60 Hz BN 546423C0201 115 V AC, 50 Hz/60 Hz

- Connect RF using connectors according to IEC 339 only.
- Relieve all connections to the dummy load from any bending torque, e.g. caused by heavy cables or assemblies.
- Check sufficiently dimensioned PE-connection and PE-continuity prior to commissioning.
- Check functioning of the interlock loop by pushing the emergency stop (S2).
   To reset the emergency stop, pull it out, pull the mains plug, wait about 30 seconds and then reconnect mains.



#### 7 Commissioning and normal operation



Before you start, ensure to read and understand the section safety messages and in particular chapter 1 "Safety" of this product manual. Only electrically skilled persons may commission and operate SPINNER dummy loads in accordance with the national safety and accident prevention regulations. Failure to observe could result in death or serious injury.

Before applying RF power to the dummy load electrically skilled persons have to ensure:

- proper connection of all system connectors
- proper functioning of the interlock loop, all relevant transmitters must be connected to the interlock system of the dummy
- unobstructed air circulation; do not cover the ventilation openings
- the green indicator lights

#### 8 Cleaning



Before you start, ensure to read and understand the section safety messages and in particular chapter 1 "Safety" of this product manual. Only trained persons may clean SPINNER dummy loads in accordance with the national safety and accident prevention regulations.

Failure to observe could result in death or serious injury.





Electric shock hazard Electric shock can cause severe burns and fatal injuries.

Before you start ensure to disconnect your entire system from the power supply. Utilize appropriate devices and methods to prevent accidental energizing. Do not use any liquids for cleaning.

#### WARNING

**Entanglement Hazard** 

The ventilators may entangle hair, clothing or jewellery causing death or serious

Wait until all rotating parts have stopped.

Wear a hair net and close-fitting clothing.



#### **CAUTION**

Hot surface

The resistor element heats up during normal operation and may cause burns.

Do not remove any covers shortly after use of the dummy load.

Do not touch the resistor element before cooled-down

Use a soft, but not damp duster, if cleaning of the exterior housing surfaces is required. Remove dust or dirt from the heat exchanger with compressed air or a soft brush.



#### 9 Maintenance

We recommend checking the coolant level as well as unobstructed air circulation of the heat exchanger every 6 weeks. Remove dust or dirt from the heat exchanger with compressed air or a soft brush.

## 9.1 Deaerating the cooling circuit



Before you start, ensure to read and understand the section safety messages and in particular chapter 1 "Safety" of this product manual.

Observe the attached material data sheet of the coolant.

Only qualified personnel may deaerate SPINNER dummy loads in accordance with the national safety and accident prevention regulations.

Failure to observe could result in death or serious injury.



#### **WARNING**

Electric shock hazard

Electric shock can cause severe burns and fatal injuries.

Before you start ensure to disconnect your entire system from the power supply. Utilize appropriate devices and methods to prevent accidental energizing.



#### WARNING

Radio Frequency Hazard

Radio Frequency Power can cause burns, eye injuries and electrical shock. Before you start ensure to disconnect your entire system from the power supply. Utilize appropriate devices and methods to prevent accidental energizing.



#### **CAUTION**

Hot surface

The resistor element heats up during normal operation and may cause burns.

Do not remove any covers shortly after use of the dummy load.

Do not touch the resistor element before cooled-down.



#### **CAUTION**

Poisoning Hazard

Skin or eye contact may cause irritation. Inhaling may irritate the respiratory organs. Avoid skin or eye contact. Do not inhale gases, fumes and aerosols.

Observe the attached safety data sheet M36457 of the coolant.




Wear safety gloves



Wear eye protection




- 1. Check coolant level and refill coolant if required (refer to chapter 9.3)
- 2. Deaeration of the heat exchanger:
  - Wait until no more air bubbles appear in the expansion tank.
  - Remove left side cover.
  - Open venting screw of the heat exchanger until air escapes. Close and tighten the venting screw after coolant starts to escape.



- Remove leaked coolant using a suitable cloth.
- 3. Deaeration of the remaining system except the resistor element:
  - Connect interlock and mains cables.

#### **NOTICE** Pump must not run dry.


• Push the pump button S1 on the connector panel until no more air bubbles appear in the expansion tank.





#### 4. Deaeration of the resistor element

• Remove RF connector.



- Open venting screw inside the inner conductor of the 3 1/8 "EIA connector until the seal is visible and air can escape.
- Close venting screw until stop right after coolant escapes.
- Remove leaked coolant with suitable cloth.
- Reconnect RF connector.

#### **NOTICE**

Faultless functioning of the dummy load can only be guaranteed, if the cooling system is deaerated properly. The coolant has to be clear and free of any bubbles.

#### 9.2 Checking glycol concentration



Before you start, ensure to read and understand the section safety messages and in particular chapter 1 "Safety" of this product manual. Observe the material data sheet of the coolant. Only qualified personnel may check the glycol concentration of SPINNER dummy loads in accordance with the national safety and accident prevention regulations.

Failure to observe could result in death or serious injury.



#### WARNING

Electric shock hazard

Electric shock can cause severe burns and fatal injuries.

Before you start ensure to disconnect your entire system from the power supply. Utilize appropriate devices and methods to prevent accidental energizing.

#### **WARNING**



Radio Frequency Hazard

Radio Frequency Power can cause burns, eye injuries and electrical shock. Before you start ensure to disconnect your entire system from the power supply. Utilize appropriate devices and methods to prevent accidental energizing.





#### **CAUTION**

Poisoning Hazard

Skin or eye contact may cause irritation. Inhaling may irritate the respiratory organs. Avoid skin or eye contact. Do not inhale gases, fumes and aerosols. Observe the attached safety data sheet M36457 of the coolant.



Wear safety gloves



Wear eye protection

Check for sufficient glycol concentration of the coolant at least annually.

Unscrew the cap of the coolant filling port.

Measure glycol concentration with usual antifreeze testing device for ethylene glycol. The optimum glycol concentration is 39 % (equals antifreeze up to -24 °C).

Below 34 % glycol concentration (equals antifreeze up to -19 °C) Coolant needs to be replenished. Drain off excess coolant at the reservoir.

Above 44 % glycol concentration (equals antifreeze up to -29 °C) thin down coolant with distilled water. Drain off excess coolant at the reservoir.

Screw on cap of filling port.

#### 9.3 Correcting the coolant level



Before you start, ensure to read and understand the section safety messages and in particular chapter 1 "Safety" of this product manual. Observe the material data sheet of the coolant. Only qualified personnel may correct the coolant level of SPINNER dummy loads in accordance with the national safety and accident prevention regulations.

Failure to observe could result in death or serious injury.



#### WARNING

Electric shock hazard

Electric shock can cause severe burns and fatal injuries.

Before you start ensure to disconnect your entire system from the power supply.

Utilize appropriate devices and methods to prevent accidental energizing.

Do not to spill any coolant into the housing of the dummy load.



#### WARNING

Radio Frequency Hazard

Radio Frequency Power can cause burns, eye injuries and electrical shock. Before you start ensure to disconnect your entire system from the power supply. Utilize appropriate devices and methods to prevent accidental energizing.





#### **CAUTION**

Poisoning Hazard

Skin or eye contact may cause irritation. Inhaling may irritate the respiratory organs. Avoid skin or eye contact. Do not inhale gases, fumes and aerosols. Observe the attached safety data sheet M36457 of the coolant.



Wear safety gloves



Wear eye protection

Refilling of coolant is necessary at coolant level below the marked minimum. The coolant level may exceed the marked maximum at temperatures above 25 °C.


#### **NOTICE**

If refill is required, use only coolant according to the specifications given in the attached data sheet.

Required coolant: SPINNER part number BN A74423 (30 litres canister)

Do not refill coolant via the drain hose or the hose connection.

Deaeration of the cooling circuit is mandatory after refilling (see chapter 9.1).



- 1 Drain hose
- 2 Nozzle adaptor
- 3 Cap for coolant filling
- 4 Coolant level indicator
- 5 Maximum coolant level
- 6 Minimum coolant level

To refill, remove the cap (3), if necessary, unscrew the nozzle adapter (2) with drain hose (1) beforehand.

#### 10 Warranty

Do not disassemble the dummy load. The warranty is void, if the dummy load is modified, improperly handled or third-party intervention or modification has occurred.

#### 11 Repairs

Troubleshooting and repairs must be only carried out by qualified technical personnel or an instructed person under the direction and supervision of qualified personnel (refer to chapter 1.4 "Qualifications of personnel"). The safety instructions and in particular chapter 1. "Safety" of this product manual must be observed.



Do not open components to avoid the risk of electric shock and personal injury.

Electrically skilled persons may reset triggered motor protection switches integrated in the inverters or replace tripped mains fuses.



If the motor protection of the inverter FU1 has tripped: Pull the mains plug, wait about 30 seconds and then reconnect mains.

If the green indicator lamp "READY" and the red indicator lamp "WARNING" do not lit although mains is connected, check the mains inlet fuses. Unplug the mains connector at the back of the control cabinet to get access to the twin fuse tray. Pull out the tray and replace the tripped fuses size 5x 20 mm:

BN 541423C0200 250 V AC, 5 A T (time-lag) BN 541423C0201 250 V AC, 10 A T (time-lag)

To reset the emergency stop, pull it out, pull the mains plug, wait about 30 seconds and then reconnect mains.

#### 12 Demounting



Before you start, ensure to read and understand the section safety messages and in particular chapter 1 "Safety" of this product manual. Only electrically skilled persons may demount SPINNER dummy loads in accordance with the national safety and accident prevention regulations.

Failure to observe could result in death or serious injury.



#### WARNING

Electric shock hazard

Electric shock can cause severe burns and fatal injuries.

Before you start ensure to disconnect your entire system from the power supply. Utilize appropriate devices and methods to prevent accidental energizing.

#### **WARNING**



Radio Frequency Hazard

Radio Frequency Power can cause burns, eye injuries and electrical shock. Before you start ensure to disconnect your entire system from the power supply. Utilize appropriate devices and methods to prevent accidental energizing.

#### **CAUTION**



Hot surface

The resistor element heats up during normal operation and may cause burns.

Do not remove any covers shortly after use of the dummy load.

Do not touch the resistor element before cooled down.



#### **WARNING**



Crushing Hazard Falling objects may cause death and serious injury.

The dummy load is heavy. Use suitable lifting gear and the lifting lugs of the dummy load only. The lifting gear must be approved to carry at least 85 kg.

Do not lift the dummy load at the RF connector.



Safety shoes are required. If it is necessary to stand below the dummy load during installation, safety shoes and hardhat are required.



#### Disconnect in the following order:

- Interlock loop connector
- · Mains cable
- RF cable
- Separate PE conductor

## 13 Disposal



#### **CAUTION**

Poisoning Hazard

Skin or eye contact may cause irritation. Inhaling may irritate the respiratory organs. Avoid skin or eye contact. Do not inhale gases, fumes and aerosols. Observe the attached safety data sheet M36457 of the coolant.



Wear safety gloves




Wear eye protection

#### **Empty the cooling circuit:**

- Remove right side cover.
- Unscrew cap of filling port.
- Place a suitable collective vessel below radiator.
- Open coolant drain screw to empty the cooling circuit.

**NOTICE** Residual quantities remain in the cooling circuit



The user is responsible for disposing of the dummy load in accordance with the national waste disposal regulations. Improper disassembly or disposal may be hazardous.

Observe the material data sheet of the coolant.

Please contact SPINNER in advance, before returning the dummy load for disposal.



## 14 Spare Parts

Designation	Order-No.	Qty.
Mains cable connector	BN 071797	1
Interlock cable connector	BN 102964	1
Coolant 30 litres canister ANTIFROGEN N	BN A74423	1

#### 15 Contacts

#### **SPINNER GmbH • Headquarters**

Erzgiessereistr. 33 80335 München **Germany** 

tel.: +49 89 12601-0 fax: +49 89 12601-1292 info@spinner-group.com www.spinner-group.com

**SPINNER Telecommunication** 

**Devices Co., Ltd.**351 Lian Yang Road
Songjiang Industrial Zone
Shanghai
201613 P.R. **China** 

tel.: +86 21 577 45377 fax: +86 21 577 40962

info-china@spinner-group.com